9V DC
⊕ ⊙ ⊝

TONE:
Controls overall tone of the effect.
Clockwise for brighter sounds.

LEVEL:
Controls Output Level of pedal
+25dB of Boost

DRIVE:
Clockwise for more
Distortion / Saturation
Turn off for Clean Boost

PHAT Switch:
Right for increased bass response
Left Fc=736Hz, Right Fc=66Hz

CLIPPING Switch:
Left for more saturation,
tighter distortion (Magical
Diodes)

Right for more dynamics
and increased output level
(Mythical Diodes)

LEVEL

DRIVE

PHAT   TONE   CLIPPING

OUT

OXBLOOD ♈

IN

ON/OFF

OXBLOOD ♈

OVERDRIVE

EFFECT TYPE:
Overdrive / Boost

Power Requirement:
9V Battery or 9VDC Center
Negative 23mA+ Power Supply

Input/Output:
Mono Instrument In,
Mono Instrument Out