



OVERDRIVE

CONTROLS

VOLUME - Controls the overall volume of the pedal. Left is less, right is more.

BODY - Controls the overall brightness of the tone. Left is darker, right is brighter.

DRIVE - Controls the amount of drive or gain. Left is less, right is more.

GAIN TOGGLE - Gives you two options for different gain types. Down is more saturated and compressed with slightly lower volume. Up is more open and crunchy with higher volume.

JACKS

INPUT - 1/4" jack on the right side of the pedal.

OUTPUT - 1/4" jack on the left side of the pedal.

POWER - Requires 9V DC negative center power and consumes 12mA. Do not use more than 9V DC. You will void your warranty.