



THE KILT

JHSPEDALS

A tone tweakers dream pedal. Boost, overdrive, distortion, fuzz and spitting chaos in one box. Don't be seen without your Kilt on.

Controls

FOOTSWITCHES

LEFT FOOTSWITCH - Engages the left "dirt" side.

RIGHT FOOTSWITCH - Engages the right "boost" side.

KNOBS

LEFT "DIRT" SIDE

VOLUME - Controls the output volume.

TONE - Controls the amount of brightness. Right is brighter, left is darker.

GAIN - Controls the amount of drive, or distortion.

RIGHT "BOOST" SIDE

BOOST - Controls the output volume of the boost. The boost will add just a slight amount of grit to your signal.

Toggles

LOW CUT TOGGLE - The down position is the stock mode with the most bass. The up position is the "cut" mode with less bass.

G1 & G2 TOGGLES - These toggles work together to give you up to 4 different resistance clipping options. Both toggles down is the lowest gain setting. G1 up gives you more overdrive. G2 up gives you more fuzz. Both toggles up gives you the heaviest gated fuzz the Kilt offers!

ORDER TOGGLE - Selects the order of the two effects. Down is Boost > Dirt, up is Dirt > Boost.

Jacks

INPUT - Jack on the right side of the pedal.

OUTPUT - Jack on the left side of the pedal.

POWER - Uses 9V DC Negative Center. Do not use more than 9V DC. Your warranty will be voided.
100mA max consumption.