
Context™ 2 is a reverb inspired by 1980's rack mount reverbs. Eight algorithms give you a wide array of classic and novel reverb sounds. Reverb decay adjusts from very tight to nearly endless, with two types of infinite hold. Predelay, low, and high frequency give extensive control over the sound. Modulation and dynamics create responsive, evolving reverb.

The room, hall, cathedral, gated, and plate reverbs are updated versions of the original Context algorithms. Spring is an algorithmic reverb modeled after amp spring reverbs. Reverse reverb fades in from a distance. The grain algorithm creates ghostly modulated feedback and clouds of sound fragments.

Dual reverb engines allow preset changes with spillover, split, serial, and parallel configuration. Stereo input and output, a full MIDI implementation, USB, and a web-based editor allow you to integrate the Context into any pedalboard or studio.

### CONTEXT



- 1 Preset / hold
- 2 Preset LED
- 3 Low response
- 4 High response
- nigit responsi
- Wet/dry blendUSB MIDI
- 7 9V DC 250 mA
- 8 Output (TRS)
- Predelay

- 10 Control port
- 1 Input (TRS)
- 12 Reverb time
- 13 Algorithm
- 14 Modulation Amount
- 15 Shift button
- 16 Bypass indicator
- 1 Bypass / hold

# CONTROLS

#### BLEND

Dry/wet blend.

#### PRE

Pre-delay from 0-100 ms.

#### **DECAY**

Reverb decay time.

#### MOD

Modulation character and amount. REV: adds forward reverb. SPRING: amp-style tremolo. other: reverb modulation.

#### Н

High-frequency response. Adjusts from dark reverb to damping to added presence.


#### LO

Low-frequency response. Adjusts from low boost to damping to highpass.

### ALGORITHM

Reverb algorithm.

### **CONTEXT - SHIFT**



10 Control port

1 Input (TRS)

12 Delay feedback

B Delay note division

Modulation Rate

16 Bypass indicator

15 Shift button

Trails on/off

- Save preset
- 2 Preset LED
- 3 Dynamics threshold
- Dynamics release
- 5 Rev/Del balance
- 6 USB MIDI
- **7** 9V DC 250 mA
- 8 Output (TRS)
- Delay time

# SHIFT CONTROLS

Hold the **SHIFT** button to access these controls. Double press for shift lock. Settings are saved when power is off.

#### BAL

Reverb/delay balance.

#### DELAY

Delay time from 0-800 ms.

#### **FDBK**

Delay feedback.

#### RATE

Modulation Rate.

### ••• (Dynamics Release Time)

Turn left for ducking reverb, right for reverb expander. Sets recovery time. Center is off.

### ----(Dynamics Threshold)

Sets the signal level where dynamics kick in. LED is green for signal below threshold, red above threshold.

### DIV

Delay tap tempo note division.



# **PRESETS**

Press the **PRESET** footswitch to switch between the knob settings and preset. To save the current sound, hold the **SHIFT** button and press the **PRESET** footswitch.

127 presets are available via MIDI program change messages. To save a preset, hold down the **SHIFT** button while sending a MIDI program change. MIDI program 128 activates the knob settings.

# **INFINITE HOLD**

Hold the left or right footswitch for infinite hold (reverb freeze).

**ON:** hold current reverb, play live sound dry.

**PRESET:** hold current reverb, use other (knob or preset) reverb for live signal.

# **POWER**

Use an isolated, well-regulated 9V DC power supply that can deliver 250 mA or more. See our knowledge base for information about specific power supplies.

If the pedal detects a problem with the power supply, the bypass LED will turn magenta and switch to bypass.

### **CTRL PORT**

The CTRL (control) port supports:

- expression pedal
- control voltage (0-3.3V)
- Red Panda Remote 4 (or DIY switches)
- Tap tempo (normally open)
- 1/4" MIDI (via 3rd-party adapters)

# **USB PORT**

The Mini USB port supports:

- firmware updates
- MIDI

### RESOURCES

Owner's Manual: www.redpandalab.com/downloads

Firmware updates:

www.redpandalab.com/downloads

Web-based editor (requires Chrome): www.redpandalab.com/web-editor

Knowledge Base: www.redpandalab.com/support

# WARRANTY

This product is warranted against defects in materials and workmanship for one (1) year from date of original purchase. It does not cover damages or wear resulting from accident, misuse, abuse, or unauthorized adjustment and/or repair. Should this product require service (or replacement at our option) while under warranty, please contact support@redpandalab.com.

#### SPECS

Input impedance: 1 M $\Omega$ Output impedance: < 470  $\Omega$ 

Max. input: +5.5 dBu (default), +8 dBu max

Bypass: analog buffered
Power: 9V DC, center negative

Current: 250 mA

### **EXPRESSION PEDAL**

Use a pedal with a 10-25  $k\Omega$  linear pot.

- Hold right footswitch while plugging in exp.
- Move to heel position, adjust knobs.
- Move to toe position, adjust knobs.
- Hold right footswitch for 2 seconds to save.

# **REMOTE 4**

- Hold right footswitch while plugging in.
- · Press footswitch for desired mode.
- Hold right footswitch for 2 seconds to save.



