



T-M-12 phase

Owner's Manual

All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

CONTROLS

SWITCH

FEEDBACK - Controls the intensity of feedback signal. **DEPTH -** Controls the depth of phase.

FOOT SWITCH - turn on/off the pedal.

RATE - Controls the speed of phase. Clockwise is speed up,left is slow down.

JACKS

This pedal should be operate at 9V DC Negative Center. If the use of other specifications of the power supply cause damage. Your warranty will be voided.

INPUT - 1/4" jack on the input side. **OUPUT -** 1/4" jack on the output side.